

**REQUIRED ITEMS**

## 1. Tools

- Set of Allen Keys
- Flat head screwdriver
- Little rope

## 2. New Tension Spring A &amp; B

**3-step replacement process:**

1. Remove the Superkop housing from the wall or base standby unscrewing the 2 screws on top and bottom of the housing; this will expose the back of the Superkop, with the Gas Spring and the two Tension Springs A & B on the back of the housing.
2. Remove the Broken Tension spring(s) by hooking a small loop of string around the Spring. Pull on the String to remove the Spring from the bar. The short one is Tension Spring A. The longer is Tension Spring B.
3. Hook/Click the new Tension Spring from underneath in place around the cross rod and put the other side of the Spring around the 2<sup>nd</sup> cross rod. You can use the String for this. See picture and instruction movie.

Well done! Now enjoy your espresso!

Superkop, easy-to-handle.

